

Download or Print Instructions | Contact: help@mcarbo.com | Page 1







Step 1: Clear your Firearm - Check the chamber, the bolt face and magazine well.



Step 2: Gather Parts and Tools Needed



. Mosin-Nagant 91/30 Trigger Spring Kit

- Bench Block
- 3. 3/32" Punch
- 4. 1/16" Punch
- 5. Hammer
- Flat head Screwdriver
- 7. Eye Protection
- 8. Firearm schematics (Optional)

Step 3: Remove bolt by pulling the bolt all the way out and pulling down the trigger








Download or Print Instructions | Contact: <a href="mailto:help@mcarbo.com">help@mcarbo.com</a> | Page 2







Step 4: Remove both the rear and front barrel bands, press on the spring and use flathead screwdriver to pop the band and pull the bands through until it's at the front sight



Step 5: Front hand guard will come right off



Step 6: Turn the Mosin upright and remove the front takedown screw from the trigger guard



Step 7: Remove the long takedown screw from the rear of the receiver





Download or Print Instructions | Contact: help@mcarbo.com | Page 3






Step 8: Remove trigger guard



Step 10: Disassemble the bolt



Step 12: Show the firing pin



Step 9: Separate stock from receiver barrel, Place the firearm upright and let the weight from the receiver barrel separate from the stock



Step 11: Pull back on the cocking piece and rotate





Download or Print Instructions | Contact: <a href="mailto:help@mcarbo.com">help@mcarbo.com</a> | Page 4





Step 13: Remove the bolt head



Step 14: Rotate the bolt head to separate the connector rod



Step 15: Use the connector rod to disassemble and loosen the bolt



Step 16: Press on the table to have the bolt come out and make sure you are pressing down hard to not have it fly back and hit you









Download or Print Instructions | Contact: <u>help@mcarbo.com</u> | Page 5







Step 17: Remove the firing spring and the firing pin from the bolt body



Step 19: You can us the bench block as a 90 degree angle or any 90 degree angle to sand the cocking piece (Small minor adjustments)



Step 18: Open up the trigger spring kit for the Mosin





Step 20: Refer to video for the polishing of the cocking piece



Download or Print Instructions | Contact: <a href="mailto:help@mcarbo.com">help@mcarbo.com</a> | Page 6








You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.

Step 21: Removing the pin from the trigger



Step 22: Remove the sear by using the flathead screwdriver to unscrew the sear screw





Step 23: Separate the trigger and the sear from each other



Step 24: Sand the back side on top of the sear on a 90 degree angle you car use your bench block.

(Use small movements back and forth)





Download or Print Instructions | Contact: <a href="mailto:help@mcarbo.com">help@mcarbo.com</a> | Page 7

You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified qunsmith. Modifying your weapon may be prohibited in your state

Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and





Step 25: Refer to video for the rest of the polishing

all legal, health and warranty consequences that may be incurred.


Step 26: Grab the sear shims and coat them in grease



Step 27: Place the sear shims where the sear screw goes



Step 28: Place the trigger and sear in together



Step 29: Place sear in trigger and place in together



Step 30: Insert the sear screw and tighten it right up



Step 31: Make sure the tip of the sear is lined up with the back end of the sear





Download or Print Instructions | Contact: <a href="mailto:help@mcarbo.com">help@mcarbo.com</a> | Page 8





Step 32: Coat the trigger shims in grease



Step 33: Insert trigger shim in the trigger, make sure they line up



Step 34: Place the hinge pin in half way to hold one of the shims in place while placing the other one



Step 35: Make sure both of the shims are lined up and push the hinge pin through








Download or Print Instructions | Contact: <a href="mailto:help@mcarbo.com">help@mcarbo.com</a> | Page 9







Step 36: If the shims don't fit properly remove the hinge pin and remove the shims to be able to sand them, sand the thickness of the shims, refer back to step 32 for installing



Step 38: Need the 550 cord gut to go through the coils of the trigger return spring





Step 37: Place trigger return spring in the trigger with one of the legs being bent in and the other leg is bent upward



Step 39: Push the hinge pin out a small amount (try to not move the trigger shims to much)







Download or Print Instructions | Contact: help@mcarbo.com | Page 10







Step 40: Place the 550 cord gut through the trigger



Step 41: Use the 550 cord gut to place the trigger return spring. Put pressure when pulling the cord gut.



Step 42: Use the punch to help place the trigger return spring in the trigger



Step 43: Place the hinge pin back through (Check shims to make sure they are in place)






Download or Print Instructions | Contact: help@mcarbo.com | Page 11













Step 46: Place the M\*Carbo firing spring on the Firing pin



Step 47: Insert firing pin and spring into the bolt body



- Bolt body
- 2. Cocking Pieces
- 3. Firing Pin
- 4. Firing Pin Spring
- Guide Rod Connector
- Bolt Head







Download or Print Instructions | Contact: help@mcarbo.com | Page 12






You must be 18 yrs of age to purchase. We advise that all parts purchased from our inventory be installed and inspected by a qualified gunsmith. Modifying your weapon may be prohibited in your state. Do not modify your sear or hammer engagement surfaces. Before installing please be sure to check all local state and federal laws. By installing this part you agree to take full responsibility for any and all legal, health and warranty consequences that may be incurred.



Step 48: Compress the trigger spring in the bolt body on the table and twist the cocking piece, use the back part of the Guide Rod Connector as a wrench to tighten the cocking piece on the bolt body.



Step 49: Make sure the cocking piece is in line.



Step 50: Insert the Guide Rod Connector and Bolt Head in the firing pin. Make sure the notch is inserted on the engagement surface.





Download or Print Instructions | Contact: help@mcarbo.com | Page 13







Step 51: Turn the cocking piece to its cock position



Step 52: Place the bolt back into the receiver





Download or Print Instructions | Contact: help@mcarbo.com | Page 14





Step 53: Place the stock on the barrel and receiver group (Make sure the trigger point is pointing straight up)



Step 54: Place the trigger through the stock



Step 55: Place the trigger guard



Step 56: Place the forward takedown screw on the trigger guard and screw it in





Download or Print Instructions | Contact: help@mcarbo.com | Page 15






Step 57: Flip the firearm around and place the rear takedown screw and screw it in



Step 58: Place the hand guard lined up



Step 59: Place the barrel bands back and lock in place (Make sure the partitions stay at the bottom)





Download or Print Instructions | Contact: <a href="mailto:help@mcarbo.com">help@mcarbo.com</a> | Page 16





